

# Quattro Inverter/Charger

3kVA - 15kVA

# Lithium Ion battery compatible

www.victronenergy.com



Quattro 48/5000/70-100/100



Quattro 48/15000/200-100/100

## Two AC inputs with integrated transfer switch

The Quattro can be connected to two independent AC sources, for example the public grid and a generator, or two generators. The Quattro will automatically connect to the active source.

#### Two AC Outputs

The main output has no-break functionality. The Quattro takes over the supply to the connected loads in the event of a grid failure or when shore/generator power is disconnected. This happens so fast (less than 20 milliseconds) that computers and other electronic equipment will continue to operate without disruption.

The second output is live only when AC is available on one of the inputs of the Quattro. Loads that should not discharge the battery, like a water heater for example, can be connected to this output.

#### Virtually unlimited power thanks to parallel operation

Up to 6 Quattro units can operate in parallel. Six units 48/10000/140, for example, will provide 48kW / 60kVA output power and 840 Amps charging capacity.

#### Split phase options

Two units can be stacked to provide 120-0-120V, and additional units can be paralleled up to a total of 6 units per phase, to supply up to 30kW / 36kVA of split phase power.

Alternatively, a split phase AC source can be obtained by connecting our autotransformer (see data sheet on www.victronenergy.com) to a 'European' inverter programmed to supply 240V / 60Hz.

#### Three phase capability

Three units can be configured for three phase output. But that's not all: up to 6 sets of three units can be parallel connected to provide 144kW / 180kVA inverter power and more than 2500A charging capacity.

# PowerControl - Dealing with limited generator, shore side or grid power

The Quattro is a very powerful battery charger. It will therefore draw a lot of current from the generator or shore side supply (16A per 5kVA Quattro at 230VAC). A current limit can be set on each AC input. The Quattro will then take account of other AC loads and use whatever is spare for charging, thus preventing the generator or mains supply from being overloaded.

#### PowerAssist - Boosting shore or generator power

This feature takes the principle of PowerControl to a further dimension allowing the Quattro to supplement the capacity of the alternative source. Where peak power is so often required only for a limited period, the Quattro will make sure that insufficient mains or generator power is immediately compensated for by power from the battery. When the load reduces, the spare power is used to recharge the battery.

# Solar energy: AC power available even during a grid failure

The Quattro can be used in off grid as well as grid connected PV and other alternative energy systems. Loss of mains detection software is available.

# System configuring

- In case of a stand-alone application, if settings have to be changed, this can be done in a matter of minutes with a DIP switch setting procedure.
- Parallel and three phase applications can be configured with VE.Bus Quick Configure and VE.Bus System Configurator software.
- Off grid, grid interactive and self-consumption applications, involving grid-tie inverters and/or MPPT Solar Chargers can be configured with Assistants (dedicated software for specific applications).

#### **On-site Monitoring and control**

Several options are available: Battery Monitor, Multi Control Panel, Color Control panel, smartphone or tablet (Bluetooth Smart), laptop or computer (USB or RS232).


# **Remote Monitoring and control**

Victron Ethernet Remote, Venus GX and the Color Control Panel.


Data can be stored and displayed on our VRM (Victron Remote Management) website, free of charge.

# Remote configuring

When connected to the Ethernet, systems with a Color Control panel can be accessed and settings can be changed.



Color Control panel, showing a PV application



Quattro	12/3000/120-50/50 24/3000/70-50/50	12/5000/220-100/100 24/5000/120-100/100 48/5000/70-100/100	24/8000/200-100/100 48/8000/110-100/100	48/10000/140- 100/100	48/15000/200- 100/100
PowerControl / PowerAssist			Yes	100/100	100/100
ntegrated Transfer switch			Yes		
AC inputs (2x)		Input voltage range: 187-	265 VAC Input frequency:	45 – 65 Hz Power factor:	1
Naximum feed through current (A)	2x 50	2x100	2x100	2x100	2x100
		INVERTER			
nput voltage range (V DC)		9	,5 – 17V 19 – 33V 38 –	66V	
Output (1)		Output voltage	e: 230 VAC ± 2% Freque	ncy: 50 Hz ± 0,1%	
Cont. output power at 25°C (VA) (3)	3000	5000	8000	10000	15000
ont. output power at 25°C (W)	2400	4000	6500	8000	12000
ont. output power at 40°C (W)	2200	3700	5500	6500	10000
Cont. output power at 65°C (W)	1700	3000	3600	4500	7000
Peak power (W)	6000	10000	16000	20000	25000
Aaximum efficiency (%)	93 / 94	94 / 94 / 95	94 / 96	96	96
Zero load power (W)	20 / 20	30 / 30 / 35	45 / 50	55	80
ero load power in AES mode (W)	15 / 15	20 / 25 / 30	30 / 30	35	50
ero load power in Search mode (W)	8/10	10/10/15	10 / 20	20	30
		CHARGER			
harge voltage 'absorption' (V DC)	14,4 / 28,8	14,4 / 28,8 / 57,6	28,8 / 57,6	57,6	57,6
harge voltage 'float' (V DC)	13,8 / 27,6	13,8 / 27,6 / 55,2	27,6 / 55,2	55,2	55,2
torage mode (V DC)	13,2 / 26,4	13,2 / 26,4 / 52,8	26,4 / 52,8	52,8	52,8
harge current house battery (A) (4)	120 / 70	220 / 120 / 70	200 / 110	140	200
harge current starter battery (A)			4 (12V and 24V models only	()	
attery temperature sensor			Yes		
		GENERAL			
uxiliary output (A) (5)	25	50	50	50	50
rogrammable relay (6)	3x	3x	3x	3x	3x
rotection (2)			a-g		
E.Bus communication port			se operation, remote monito	oring and system integration	on
General purpose com. port	2x	2x	2x	2x	2x
Remote on-off			Yes		
Common Characteristics			) to +65°C Humidity (non-o	condensing): max. 95%	
		ENCLOSURE			
Common Characteristics			minium (blue RAL 5012) Pi		
Battery-connection		Four M8	bolts (2 plus and 2 minus co	nnections)	
230 V AC-connection	Screw terminals 13 mm <sup>2</sup> (6 AWG)	Bolts M6	Bolts M6	Bolts M6	Bolts M6
Weight (kg)	19	34 / 30 / 30	45 / 41	51	72
		470 x 350 x 280		5.	72
Dimensions (hxwxd in mm)	362 x 258 x 218	444 x 328 x 240	470 x 350 x 280	470 x 350 x 280	572 x 488 x 344
		444 x 328 x 240			
		STANDARDS			
Safety			0335-1, EN-IEC 60335-2-29,		
Emission, Immunity	EN 5501	4-1, EN 55014-2, EN-IEC 610	000-3-2, EN-IEC 61000-3-3, IE	,	2, IEC 61000-6-3
Road vehicles			12V and 24V models: ECE	R10-4	
Anti-islanding			See our website		
1) Can be adjusted to 60 HZ; 120 V 60 Hz on re 2) Protection key:	equest	<ol> <li>3) Non-linear load, cre</li> <li>4) At 25°C ambient</li> </ol>	st factor 3:1		
a) output short circuit			no external AC source available		
b) overload			y that can a.o. be set for general	alarm,	
c) battery voltage too high			genset start/stop function		
d) battery voltage too low e) temperature too high		AC rating: 230 V / 4	A 35 VDC, 1 A up to 60 VDC		
f) 230 VAC on inverter output		De lating. 4 A up to	55 VDC, 1 A up to 00 VDC		
g) input voltage ripple too high					
All areas and	Commu	ter controlled operatio	n and manitoring		
		terfaces are available:	and monitoring	Active service	
BA Barrier Bar	Several II	iterraces are available:		- W0	
	No. of Concession, Name			080	
	TION TION	Color Contr	ol GX		
Digital Multi Control Panel	92. T	Monitoring ar	nd control. Locally, and also	BMV-700 B	attery Monitor
convenient and low cost solution for	remote	remotely on t	he <u>VRM Portal.</u>		Battery Monitor featur
nonitoring, with a rotary knob to set	0				microprocessor contro
owerControl and PowerAssist levels.				system comb	vined with high
				resolution m	easuring systems for
					ge and charge/discharg
			E.Bus to USB interface	current. Besi	des this, the software
				includes com	plex calculation
		VEConfigure')	USB port <u>(see 'A guide to</u>		ke Peukert's formula, to
	5				mine the state of charg
					y. The BMV-700
				selectively di	splays battery voltage,
					umod Ab ar tirre to
				current, cons	umed Ah or time to go
			MEA 2000 interface		umed Ah or time to go
		Connects the	device to a NMEA2000 mari	ne	umed Ah or time to go
		Connects the	device to a NMEA2000 mari twork. See the <u>NMEA2000 8</u>	ne	umed Ah or time to go

Victron Energy B.V. | De Paal 35 | 1351 JG Almere | The Netherlands General phone: +31 (0)36 535 97 00 | E-mail: <u>sales@victronenergy.com</u> www.victronenergy.com

